

INSTALLATION

The Wade 3000-DF is used for conventional roof membrane insulated systems. The insulation thickness must be determined before ordering the drain assembly. The cast iron fixed extensions are furnished in standard heights in one inch increments. For proper installation, an optional bearing pan and underdeck clamp are recommended.

1. At the predetermined location, cut a circular opening into the deck to recieve the bearing pan. The pan is recessed to allow the drain body to sit almost flush with the deck.

2. Install the drain body into the bearing pan and secure with the underdeck clamp from underneath. Installation of piping may then proceed.

3. On the roof side, install the fixed extension. The supplied o-ring seal installs in a groove on the bottom of the extension. A gasket sealant may be applied to hold the gasket in place. The threaded rods shoul be installed prior to seating the fixed estension - the rods will act as a guide to properly align the extension. secure the extension with the supplied hardware.

4. The insulation is applied - it should be flush with the top surface of the fixed extension. If the insulation is thicker than the top surface of the extension flange, taper the insulation from a 24" diameter to the top surface of the flange. Apply the waterproof membrane per manufacturers recommendations. Membrane must lay flat and contour the opening. Install the flashing ring with the provided hardware, securely fastening the membrane between the body and the flashing ring. Gravel ballast is evenly spread over the membrane up to the perimeter of the gravel stop.

5. The dome is installed by a setting into the ring and twisting to lock.

Dimensional Data (Inches/mm)

are Subject to Manufacturers Tolerance and Change Without Notice.

Job Location

