

# ADJUSTABLE FLOOR CLEANOUT



Approval Date

Customer Approval


Job Location

Job Name

Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data

## 6000-CF

CAST IRON ADJUSTABLE FLOOR CLEANOUT WITH SATIN FINISH NICKEL BRONZE TOP ASSEMBLY, PLASTIC HOUSINGS, VANDAL PROOF SECURED COVER, CARPET FLANGE AND BOTTOM OUTLET.  
INSTALLATION INSTRUCTIONS



The Wade 6000-CF adjustable floor cleanout is used for carpet areas. The drain piping is first run to an elevation below the expected finish floor level. The body ( ferrule ) is secured to the pipe with with any of three connections; No-Hub, Inside Caulk, or Push-On Ty-Seal. The type of connection must be specified upon ordering most Wade cleanouts. If the Ty-Seal connection is specified, apply Tyler Ty-Seal lubricant to the inside surfaces of the gasket and then firmly push the cleanout ferrule onto the pipe until it contacts the pipe stop in the body. No-Hub outlets should be installed with Tyler or Anaco/Husky couplings and secured with a torque wrench to the manufacturers recommendations. Inside Caulk connections should follow standard industry practices.

Once the ferrule is connected to the pipe, the initial concrete sub-floor is poured to an elevation level with the flange of the ferrule. The waterproofing membrane is applied to the the sub-floor surface, covering the ferrule flange and up to the perimeter of the body. The top assembly is aligned over the ferrule - make sure the plastic tabs match the beveled areas on the ferrule. Firmly push the top down until it contacts the membrane at the ferrule flange. Before the second pour, remove the carpet flange and scoriated cover. The adjustable top assembly threads up or down to the desired dimension. The cleanout top should be at the floor level or slightly below for the final pour. After final pour, replace carpet flange and cover for safety.

For slab on grade construction, first remove the carpet flange and cover. Install the top assembly onto the ferrule and adjust to the desired dimension. Pour concrete up to and around the perimeter of the cast iron frame. After final pour, repace carpet flange and cover for safety.

Before carpet installation, remove the carpet flange and cover. Carpet is installed over the concrete completely covering the cleanout top. After carpet installation, locate the cleanouts and use a utility knife to cut the carpet to the inside diameter of the recess. Install the carpet flange and scoriated cover using the provided hardware.

AutoCad.dwg